

SAR Distribution in Test Animals Exposed to RF Radiation

Verónica Berdiñas Torres, Andreas Christ, Niels Kuster
IT'IS Foundation, ETH Zurich, Switzerland



Eidgenössische Technische Hochschule Zürich
Swiss Federal Institute of Technology Zurich

Background & Motivation

- *in vivo* studies need to be optimized with respect to the sensitivities of the hypothesis being tested, for ethical, time and cost reasons
- one key parameter is a well defined dose of the chemical or physical agent
- detailed and accurate dosimetric information is a basic precondition to enable interpretations and valuations of the results of histopathology

Example of a Possible Misinterpretation

Experiment A

whole-body SAR = 1 W/Kg

Experiment B

whole-body SAR = 1 W/Kg

Example of a Possible Misinterpretation

Experiment A

whole-body SAR = 1 W/Kg

Liver SAR = 1-5 W/Kg

Experiment B

whole-body SAR = 1 W/Kg

Liver SAR = 0.001-0.01 W/Kg


Objectives

- generation of high resolution anatomical models of animals
- dependence of SAR values and distribution on different factors: frequency, polarization, resolution
- identification of relevant parameters for the comparison of animal studies
- to develop a universally applicable methodology for the complete, detailed dosimetric analysis of *in vivo* experiments

Methods



Simulation Tool SEMCAD X

- import and handling of complex CAD data (several 10'000 CAD parts)
- non-uniform and conformal grids (>1 billion voxels)
- highly efficient EM and thermal solvers incl. blood flow
- availability of high resolution anatomical models (CAD based)
- extraction of required quantities (E- and H-field, SAR and temperature distributions, whole-body and organ-specific average SAR, peak spatial average SAR, etc.)



Anatomical Model Requirements

- high resolution anatomical models development based in Microtom slices
- manual identification of tissues supported by software for imaging and segmentation
- anatomical resolution $\ll 1\%$ of total length (d_slice: 0.5 mm for mice & 1.2 mm for rats)



Measurement Tools DASY4 & EASY4

- E- and H-field probes ($d < 5$ mm, isotropic response of better than 0.5 dB)
- dosimetric probes ($d < 1.5$ mm, sensitivity of < 1 mW/kg, isotropic response of better than 0.5 dB)
- temperature probes (response time of < 1 s, sensitivity of < 10 mK)
- position accuracy (< 1 mm)




Relevant Parameter for the Comparison of Animal Studies


Polarization and Frequency Dependence of WB SAR

- Whole-body averaged SAR in dB (W/Kg)/(W/m²)

Mouse




Rat



Mouse Organ-Specific SAR Variations

- deviation organ-specific averaged SAR of E-, H- and k-polarization vs. WB average SAR of E-pol




Mouse Organ-Specific SAR Variations

- maximal deviation in dB of mouse organ-specific average SAR among polarizations

Frequency	Brain (dB)	Kidneys (dB)
450 MHz	10	3
900 MHz	8	2
1800 MHz	5	10
5000 MHz	2	3

Rat Organ-Specific SAR Variations

- deviation organ-specific averaged SAR of E-, H- and k-polarization vs. WB average SAR of E-pol



Rat Organ-Specific SAR Variations

- maximal deviation in dB of rat organ-specific average SAR among polarizations

Frequency	Brain (dB)	Kidneys (dB)
450 MHz	14	4
900 MHz	6	6
1800 MHz	4	5
5000 MHz	3	2



Mouse: SAR Distribution (E-polarization)

450MHz

900MHz

1.8GHz

5GHz



(0dB=1W/kg)



Rat: SAR Distribution (E-polarization)

450MHz

900MHz

1.8GHz

5GHz



(0dB=1W/kg)



Comp. of SAR Distributions (close to body res.)

Mouse @ 1.8GHz

E-pol

H-pol

k-pol





Rat @ 900MHz

E-pol

H-pol


k-pol



(0dB=1W/kg)

SAR values as a function of voxel resolution

- Rat deviation of SAR values vs. WB avg. SAR of F-F case



- CC: coarse anatomical resolution (1.2 mm) - coarse grid resolution (1.7mm³)
- CF: coarse anatomical resolution (1.2 mm) - fine grid resolution (0.2mm³)
- FF: fine anatomical resolution (0.6 mm) - fine grid resolution (0.2mm³)

Discussion


- SAR distributions highly depend on the frequency and polarization
- organ-specific SAR significantly vary, even with respect to whole-body averaged SAR
- comparable SAR distributions for mice @ 1.8GHz and rats @ 900MHz (that led NIEHS to use this scenario for their large scale studies)
- the uncertainty for WB SAR due to resolution is less than 0.5 dB
- the uncertainty at a grid resolution of 1.7mm^3 is bigger than 2 dB for peak spatial SAR

Overview of Exposure Concepts


Concept: Open Systems (Near-Field Exposures)

- reasonable efficiency
- poor uniformity
- good variability
- small space requirements
- one exciter per one or two animals
- poor to medium isolation


C.K. Chou's Loop Setup



Kain's "Coil" Setup




Carousell Setup



Concept: Open Systems (“Far”-Field)

- poor to medium efficiency
- good to reasonable uniformity
- medium variability (non-uniform incident exposure & higher modes)
- large space requirement
- one exciter per group or subgroup
- excellent isolation


Adey's Horn Setup




Concept: Quasi-Open Waveguide Systems

- medium efficiency
- reasonable uniformity
- medium variability
- medium to large space requirements
- good isolation

Guy and Chou's Circularly Polarized WG Setup




"Hansen's" RTL Setup



Concept: Multi-Mode Resonant Systems

- high efficiency
- medium to good uniformity
- considerable variability due to higher modes ($> \pm 3\text{dB}$)
- small space requirements
- one exciter per group or subgroup
- good isolation

Motorola's Ferris-Wheel Setup




PERFORM A's Mouse Setup



Concept: “Mono-Mode” Resonant Systems

- high efficiency
- good uniformity
- small variability
- small space requirements
- one exciter per animal group
- good isolation

Restrainer tube & loading mechanism



PERFORM A's Rat Setup



Concept: Statistical Multi-Mode Resonant Systems


- medium-high efficiency
- statistically uniform (<2 dB deviation) and isotropic field distribution
- small variability (for distances $>\lambda/2$)
- high space requirements
- large number of exposed animals per chamber
- 1 to 12 exciters per animal group

NIEHS's RC Prototype at IT'IS



Minimal Requirements for Dosimetry and SAR Uncertainty and Variation Assessment


Detailed Dosimetry, Uncertainty and Variations



Dosimetry & Uncertainty Assessment



- a complete dosimetry has to be performed for an average exposure or standard situation:
 - average exposure setup
 - average animal model in weight and age
 - target/average position in the setup
 - target/average posture
 - average dielectric parameters
 - verified grid resolution
- the setup model and the uncertainty analysis need to be verified/determined by a combination of experimental and numerical means
- experimental verification of the animal model is very limited, and the uncertainty needs to be assessed by inter-numerical comparison

Evaluation of Uncertainty Assessment



SAR Uncertainty Rat 1747 MHz: Anatomy

4 Different Rat Models scaled to same weight



- example from PERFORM A dosimetry
- 4 rat models scaled to average weight
- whole-body averaged SAR difference: 2.5 dB





Experimental Validation of Numerical Model

- validation is performed by loading the setup with animal phantoms that closely represent the load by animals in terms of size and absorption
- this requires an additional uncertainty analysis including the phantom and the experimental evaluation
- the dosimetry is reliable if the difference between experimental and numerical results is within the uncertainty boundary

$$E_n = \sqrt{\frac{(v_{sim} - v_{meas})^2}{[v_{sim}u_{sim}(k=2)]^2 + [v_{meas}u_{meas}(k=2)]^2}} < 1$$


Example Validation: Rat Exposure Setup 1747 MHz

- E- and H-field comparison



Example Validation: Rat Exposure Setup 1747 MHz

- SAR pattern comparison



- the final deviation E_n for averaged SAR validation was determined to be

$$E_n = \sqrt{\frac{(v_{sim} - v_{meas})^2}{[v_{sim} u_{sim}(k=2)]^2 + [v_{meas} u_{meas}(k=2)]^2}} = \mathbf{0.34}$$

Instant & Lifetime SAR Variations


SAR Variations Caused by Exposure Setup

- input power / incident fields (drift of amplifiers/measurement equipments, load differences, etc.)
- calibration differences
- mechanical and electrical differences between setups
- position occupied by the animal within the setup
- dependence on neighboring animals


SAR Variations Caused by Animals

- size/weight (highly compensated by applying weight-dependent incident power)
- anatomy (age, strain, gender)
- orientation of the animal within the field (highly compensated by using a restrainer tube)
- posture and position within the waveguide
- position of the waveguide in the setup
- wet fur (water, urine, etc.)

Evaluation of SAR Variations




Evaluation of SAR Variations





SAR Variations Mouse 902 MHz: Position in the Setup

- example from PERFORM A dosimetry
- whole-body avg. SAR variation: 2.5 dB



SAR Variations Mouse 902 MHz: Posture and Position

- example from PERFORM A dosimetry
- WB SAR variation: 0.6 dB
- WB SAR variation: 4.9 dB



Whole-body Averaged SAR Variations

- example of whole-body averaged SAR, absolute uncertainty, instant variation and lifetime variation, from PERFORM A dosimetry

Animal / Frequency	Uncertainty (k=2) (dB)	Instant Variation (k=1) (dB)	Lifetime Variation (k=1) (dB)
Mouse / 902 MHz	2.7	2.5	1.5
Mouse / 1747 MHz	2.2	2.0	1.0
Rat / 902 MHz	1.9	0.8	0.7
Rat / 1747 MHz	1.7	1.8	1.2

Spatial Peak Average SAR Variations Rat 1747 MHz

- example of whole-body peak spatial averaged SAR, absolute uncertainty, instant variation and lifetime variation, from PERFORM A dosimetry for rats exposed at 1747 MHz

Averaging Mass	Dev. SP SAR vs. WB avg SAR (dB)	Uncertainty (k=2) (dB)	Instant Variation (k=1) (dB)	Lifetime Variation (k=1) (dB)
50 mg	9.5	4.0	1.7	1.4
5 mg	10.3	4.5	1.9	1.7

Organ SAR Variations: Blood, Brain, Liver

- example of organ-specific averaged SAR, absolute uncertainty, instant variation and lifetime variation, from PERFORM A dosimetry

Animal / Frequency	Materials	Dev. Organ versus WB SAR (dB)	Uncertainty (k=2) (dB)	Instant Variation (k=1) (dB)	Lifetime Variation (k=1) (dB)
Mouse / 902 MHz	Blood	1.6	2.7	2.9	2.1
	Brain	-2.1	2.6	2.8	1.3
	Liver	0.2	2.7	2.6	1.7
Mouse / 1747 MHz	Blood	5.2	2.3	2.3	1.4
	Brain	1.0	2.3	3.1	2.0
	Liver	1.0	2.6	2.2	1.3
Rat / 902 MHz	Blood	2.6	1.6	1.1	0.9
	Brain	-4.3	5.0	2.4	1.7
	Liver	1.1	2.8	1.7	1.6
Rat / 1747 MHz	Blood	3.3	1.8	1.4	0.8
	Brain	2.9	2.5	3.3	1.4
	Liver	1.4	2.3	1.4	1.1

Discussion

- a methodology to obtain detailed dosimetric information for *in vivo* studies has been developed
- it includes:
 - whole-body and organ-specific averaged and spatial peak averaged SAR values
 - uncertainty of each assessed value
 - instant variations, variations of the averaged exposure of a single session as well as the entire lifetime
- reliable dosimetric data with reasonable effort can only be obtained if the concept of the exposure setup is well chosen
- the suggested methodology increases the reliability and credibility of the dosimetric results and provides a basis for high quality interpretations and valuations of the histopathological results (dose-effect relation)

Conclusions

- high resolution anatomical models, i.e., $< 0.2 \text{ mm}^3$ are necessary
- SAR distribution strongly depend on animal, frequency, polarization
- whole-body and organ-specific SAR is required for the interpretation and inter-study comparison
- the dosimetry of animal studies should at least include:
 - whole-body averaged SAR
 - organ-specific averaged SAR
 - peak spatial SAR (averaging masses have to be appropriately scaled)
- a comprehensive uncertainty and variation analysis is a fundamental part of good science

Acknowledgements

- This study was generously supported by
 - German Radiation Protection Agency (BfS)
 - European Union (5th Framework Program)
 - Swiss Agency for Education and Science (BBW)
 - Mobile Manufacturers Forum (MMF)
 - GSM Association (GSMA)